

SONY®

Digital Photo Printer Basic Operation Guide

Full Mode



UP-CR20L

▶ Supported Data Formats

- JPEG(Exif 2.2.1 Baseline)
- TIFF(RGB Uncompressed)
- BMP(24-bit Windows)
- Image size : 8,000 X 6,000 pixels max.

▶ Supported Memory Cards


- | | | |
|-----------------------------------|---------------------|--|
| - Memory Stick PRO (Standard/Duo) | - MultiMediaCard | - CD-R/RW, DVD-R/RW |
| - xD-Picture Card | - CompactFlash Card | (DVD+R/RW and DVD-RAM are not supported) |
| - SD Card (Standard/mini) | - Microdrive | |
| | - USB Memory | |

Caution

Before using a memory card, be sure to create a backup copy of its contents. Sony assumes no liability for lost or damaged data.

Select & Print

1 Touch the screen.




2 Select your language.*



3 Select your picture source (Memory Card or CD/DVD).




4 Insert your memory card or disc.



5 Select "Select & Print."




6 Select the print size.*



7 Touch the image you want to print.



Sets the print finish (glossy or matte) and whether or not to print dates or show file names.




Displays an enlarged view of the image.

Closes the popup display.
Sets the number of prints.

Edit it! For details on how to edit, see [Editing Images](#)

Touch a button to select menu.




Touch to display the edit menu. The following editing functions are available.
- Crop and Rotate
- Color Adjustment
- Red Eye Reduction
- Sepia/B&W

After editing, go to **7**

8 Select any other images that you want to print.



9 When you finish setting and editing the image, touch "OK."



10 After verifying the number of prints and the price, select the print finish (glossy or matte) and touch "Print Start."



11 Enter the password.*



Printing begins!

Do not remove your memory card until a message appears asking you to do so.

Make sure not to forget your prints or memory card.

* This may not be necessary in some cases.

Border Print

- 1 Touch the screen.
- 2 Select your language.*
- 3 Select your picture source (Memory Card or CD/DVD).
- 4 Insert your memory card or disc.
- 5 Select "Border Print."




- 6 Select the print size.*
- 7 Touch the border that you want to use, and touch "OK."



- 8 Touch the image you want to print.




- 9 Adjust the size and position of the image to fit the border.



- 10 Specify the number of prints. Select any other images that you want to print.



- 11 When you finish setting and editing the image, touch "OK."
- 12 After verifying the number of prints and the price, select the print finish (glossy or matte) and touch "Print Start."



- 13 Enter the password.*




Printing begins!

Make sure not to forget your prints or memory card.


* This may not be necessary in some cases.

Split Image

- 1 Touch the screen.
- 2 Select your language.*
- 3 Select your picture source (Memory Card or CD/DVD).
- 4 Insert your memory card or disc.
- 5 Select "Split Image."




- 6 Select the print size.*
- 7 Select the desired layout and then touch "OK."




- 8 Touch the frame that you want to assign an image to.



- 9 Select the image that you want to assign to the frame.




- 10 If you are laying out multiple images, select the other image.
- 11 Set the number of prints and touch "OK."



- 12 After verifying the number of prints and the price, select the print finish (glossy or matte) and touch "Print Start."



- 13 Enter the password.*




Printing begins!

Do not remove your memory card until a message appears asking you to do so.

Make sure not to forget your prints or memory card.

* This may not be necessary in some cases.

You can edit images taken with a camera for even lovelier prints. Touch the button of any menu you wish.





Undoes your edits and resets to the original image.

Closes the edit menu and returns to the original screen.

Crop & Rotate



The ability to crop images down to an essential portion and to rotate them gives you the freedom to decide an image's composition.

Cropping an Image



Use or to zoom in or out. Then, move the cropping area with .

Rotating an Image



Each time you touch , the image rotates 90 degrees clockwise. Touch until the image is oriented as you wish.

When finished editing, touch .

Red Eye Reduction

You can reduce the “red eye” effect resulting from flash photography.




To undo a correction, touch .

- 1 Use and to position the frame displayed in the preview screen around the red eye.
- 2 Touch . Perform red eye reduction on one eye at a time.
- 3 Verify the results of the correction on the preview screen. When finished making corrections, touch .

If cropping or rotation is performed after red eye reduction, the corrections for red eye are canceled. Make sure to perform red eye reduction after cropping or rotation.

Sepia/Black&White

You can process your prints in sepia or black and white to give them the look of old photographs.




→ Changes to sepia image.

→ Changes to black and white image.

After selecting an option, touch .

Color Adjustment

You can change an image's color settings, adjusting the brightness, tint, saturation, and sharpness as you wish.



Select the item you want to adjust, and touch or to change the color value. To ensure the desired color adjustment, verify results in the preview screen while making adjustments.

When finished adjusting, touch .

Index Print

- 1 Touch the screen.
- 2 Select your language.*
- 3 Select your picture source (Memory Card or CD/DVD).
- 4 Insert your memory card or disc.
- 5 Select "Index Print."



- 6 Select the print size.*
- 7 After verifying the number of prints and the price, select the print finish (glossy or matte) and touch "Print Start."




Do not remove your memory card until a message appears asking you to do so.


Make sure not to forget your prints or memory card.

Express Print

- 1 Touch the screen.
- 2 Select your language.*
- 3 Select your picture source (Memory Card or CD/DVD).
- 4 Insert your memory card or disc.
- 5 Select "Express Print."



- 6 Select the print size.*
- 7 After verifying the number of prints and the price, select the print finish (glossy or matte) and touch "Print Start."



Do not remove your memory card until a message appears asking you to do so.

Make sure not to forget your prints or memory card.

* This may not be necessary in some cases.

Maintenance Guide — For Store Clerks —


Precautions

- Be sure to replace both the ink ribbon and the paper roll as a set.
- Immediately after printing, the thermal head inside the unit will be hot. When loading the ink tray, do not insert your hand into the opening of the unit, to prevent the risk of burns.
- Always use a designated print pack.
- Do not touch the printing surface of the paper roll or the ink ribbon. Fingerprints and other pollutants can lead to reduced print quality.


Replacing the Paper Roll and Ink Ribbon

Unlocking the Ribbon Door

- 1 Touch the top left corner of the error message screen twice in succession.




- 2 Enter the administrator password using the numeric keypad, and touch **OK**.




The ribbon door unlocks.

Replacing the Paper Roll


- 1 Open the paper door.




- 2 Remove the paper roll.



- 3 Pull the paper core out of the old paper roll.




- 4 Insert the paper core into the new paper roll.



? Troubleshooting

- 5** Load the paper roll.
* Be sure to load the paper roll with the arrow on the seal pointing inside the unit.



- 6** Remove the seal affixed to the paper roll.
* Be sure to remove the seal completely. In addition, remove the seal slowly to avoid leaving parts of the adhesive on the paper.

- 7** Close the paper door.

Replacing the Ink Ribbon


- 1** Open the ribbon door.



- 2** Remove the ribbon tray.




- 3** Remove the ink ribbon.



- 4** Detach the white spool of the ink ribbon from the black spool.

- 5** Gently unravel the ribbon without loosening it, and place it in the ribbon tray.



- 6** Hold the center of the ribbon tray, and load it into the unit.



- 7** Close the ribbon door.




Symptom	Cause/Remedy
The printer does not feed the correct amount of paper automatically when you close the paper door and ribbon door after loading the paper roll and ink ribbon.	The printer may be turned off. → Turn on the printer. The paper roll may have been loaded with its left and right sides reversed. → Load the paper roll in the proper direction.
Cannot load ink ribbon.	You may be trying to load the ink ribbon spools into the wrong holders. → Load each spool into its proper holder on the ribbon tray.
Cannot load paper roll.	You may be trying to load a printing pack that is 152 mm (6 inches) in width (2UPC-R204/C26/R206 series) while the paper adapters are attached. → Remove the adapters and then load the paper roll.
Paper roll was loaded, but "no paper" message appears.	Paper roll may not have been loaded correctly. → Ensure that paper roll is loaded correctly.
Ink ribbon was loaded, but "no ink ribbon" message appears.	Ribbon may not have been loaded correctly. → Ensure that ribbon is loaded correctly.
Out of paper message appears, but there is still paper in the unit.	This is not a defect. Some spare paper will be left over. → Remove the leftover paper and load a new ink ribbon and paper roll.
There is a white margin on the printed image.	You may be trying to load a printing pack that is 127 mm (5 inches) in width (2UPC-R203/R205 series) without the paper adapters attached. → Attach the paper adapters.
A vertical white stripe appears on the printout.	Dust may have accumulated on the thermal head. → Clean the interior of the printer.

Symptom	Cause/Remedy
Display not on or difficult to see.	Depending on the display angle, the display may not be visible or may be difficult to see. → The display angle can be adjusted. Adjust the angle of the display to improve the display appearance.
Image data cannot be read.	A mounted memory card does not contain any data. → Insert a memory card that contains image data. Data has been recorded in a format that the unit does not recognize. → Be sure to store image data in a format that the unit can recognize. The memory card may not be properly inserted. → Make sure that the memory card is fully inserted. The memory card may not be inserted in the correct direction. → Set the memory card in the direction shown on the operation screen.

SONY[®]

Distributed by



MK10573V1PSG09MAR

© 2009 Sony Corporation. All rights reserved.
Reproduction in whole or in part without written permission is prohibited.
Features and specifications are subject to change without notice.
Sony is a registered trademark of Sony Corporation.
Memory Stick, Memory Stick Duo, Memory Stick PRO, Memory Stick PRO Duo, Print by Sony, Snap Lab and Pro Matte are trademarks of Sony Corporation.
All other trademarks are the property of their respective owners.