

Disabling KODAK Gallery Features on a KODAK Picture Kiosk

Effective July 2, 2012, as a result of the sale of KODAK Gallery to Shutterfly, KODAK Picture Kiosks will no longer be able to connect to KODAK Gallery.

KODAK Picture Kiosks will continue to connect to the FACEBOOK Site and PICASA Web Albums.

If you have not received the KODAK Gallery expiration package from KODAK Remote Business Manager, or the Social Networking Connectivity Module V2.0, follow the steps below to remove the KODAK Gallery Features from your Kiosks.

Turning off the KODAK Gallery as an Input Source

1. Touch:
 - [Setup], enter the password if necessary.
 - [Manage Features]
 - [Enable Input Sources]
2. Touch the box next to Enable Input from Gallery.
The feature is disabled when the check mark is removed.
3. Touch:
 - [Save]
 - [Start Over]

Turning off the KODAK Gallery Attract Loops

1. From the Setup screen, touch: [Install or Manage Modules].
2. Touch [Manage Attract Loops].
3. Touch the box next to:
 - KODAK Gallery Attract Loop
 - Online Access Attract Loop
The Attract Loops are disabled when the check marks are removed.
4. Touch [Done].

Turning off the KODAK Gallery Welcome Screen

1. From the Install or Manage Modules screen, touch [Manage Welcome Screen].
2. Touch the box next to the KODAK Gallery Welcome Screen.
Note: The name of the Welcome Screen varies depending on your store.
The Welcome Screen is disabled when the check marks are removed.
3. Touch:
 - [Done]
 - [Start Over]
 - [Exit]

