

Overview

This firmware update will add the following features to you UP-CR10L:
ProMatte finish and 4x8 prints (requires 2UPCC48PF media).

Preparation

After connecting the UP-CR10L to your PC with a USB cable (not included), turn on the printer and perform the following:

1. Double click the following file:




2. Click **R**un if the following screen appears.




3. The file will self-extract, and a software license agreement window will appear.



4. Click **I accept** to continue.



5. After you agree, the software will start upgrading the firmware automatically.



6. **Caution!** Do not turn the printer off while the firmware is being downloaded.



7. **Now updating ...** Will display on the UP-CR10L monitor for several moments.
8. The printer will restart when the installation has been completed successfully.
9. The USB cable can now be removed. This completes the firmware update.