

Printer Parts and Accessories



Parts Specifications for ID Passport Photo System

		LIST	Q1	
PCS-AC08	AC Adapter, for C200 Camera	\$ 179.99	\$ 157.99	
UPA-AC05	AC Adapter with ACCORD2890, for C300 Camera	\$ 59.99	\$ 47.99	
ACCORD2890	AC Cord, 2-wire, 90°, ID Printer and AC Adapter (Cable Length: 8ft)	\$ 14.99	\$ 11.24	
ACCORD26	AC Cord, 2-wire, ID Printer and AC Adapter (Cable Length: 6ft)	\$ 9.99	\$ 7.49	
920-2413	Battery and Charger, AA with 4 NiMH Batteries	\$ 34.99	\$ 26.24	
960-0001	Battery, AA Rechargeable, Set of 4 Batteries; NiMH	\$ 24.99	\$ 18.74	N/A
920-2414	Battery, Coin, C200 Camera, CR2025 (Retains Camera Settings)	\$ 5.99	\$ 4.49	
990-2800	Bluetooth Dongle, 1 Piece	\$ 24.99	\$ 18.74	
UPDX-CLEANCASS	Cleaning Cassette (white), for DX100 and ID400 Passport Printer	\$ 17.99	\$ 13.49	
DOC-D-ID400	Guideline Sticker Sheet, for ID400 (W or DC) Digital Camera LCD, 1 set of 3 Appliqués in Popular Sizes	\$ 24.99	\$ 19.99	
920-2416	Holder, Coin Battery, C200 Camera	\$ 39.99	\$ 29.99	