

PRINT PHOTOS FROM YOUR PHONE

1 Set your Wi-Fi connection to:
.SelfOne_WiFi_Print 

*If your browser opens automatically, tap "Start Application" and follow instructions.
*If no browser opens, proceed to Step 2

2 **iPhone**  Open Safari browser and start application | **Android**  Open Android browser and start application

*For other internet browsers, go to any webpage that starts with http:// (not https)

3 Follow on-screen instructions to select photo from your phone, or take a new picture to print.



SELFONE WIRELESS PRINT STATION™

Everyone takes pictures at a wedding, but now, you can turn their photos into an opportunity to boost the wedding package you offer, and let guests print their photos wirelessly, right from their smart phones!

- **No Apps to download**
- **No Internet access required**
- **Print your photos in just 3 easy steps**
- **Fast printing from almost any mobile device running current versions of iOS or Android operating systems.**



CP-D90DW
with SelfOne Wireless Print Station™ attached

Smart Phone
and/or Tablet

www.mitsubishi-imaging.com
TOLL FREE 888.307.0388

www.mitsubishielectric.ca
PHONE 905.475.7728

 **MITSUBISHI
ELECTRIC**
PHOTO PRINTERS



Expand your photo offerings with the SelFone Wireless Print Station™!

The SelFone Wireless Print Station™ gives you an easy way to offer and manage wireless printing at your events, enabling you to offer more to your photography services. By adding an on site WiFi printing station to your package as an upsell, you boost your bottom line with extra revenue while giving your customers lots of fun!

The SelFone Wireless Print Station™ easily attaches to the CP-D90DW Photo Printer and features a robust application that makes any professional job easy to manage. All administration operations are performed thru the WiFi browser: regulate start/stop service, reboot/shutdown, access all menus and customize print settings.

Features Include:

- **Configure Print Sizes, Modes and Format**
- **Easily Import (Enable/Disable) Frames and Borders**
- **Select Print Type Offered from: Easy Print single 4x6 photo, 2x6 3-photo strip, or 3.5x6 fun print**
- **Ability to change/rename WiFi ID makes it easier for guest users to recognize and remember the hotspot for printing**
- **Ability to set passcodes lets photographers control and restrict the use of the print services**
- **Manage and Customize Hot Folders**
- **Check Printer Media Status**
- **Monitor and Retrieve Print Statistics**
- **Ability to Clear all Print Orders**



Easy Print 4x6"
Pre-Perforated



Fun Print 2x6"
Strip



Fun Print 3.5x6"